



*HIGH SPEED  
DOME NETWORK CAMERA*



- Quick Installation Guide +
- Installationsanleitung +
- Guide d'installation +
- Guía de instalación +
- Guida di Installazione +

# Quick Installation Guide

## DCS-6915

### HIGH SPEED DOME NETWORK CAMERA

## Package Contents

If any of the items are missing, please contact your reseller.




Dome Network  
Camera



Cap



Software CD



Waterproof Collar



Screwdriver



Lubricant




Screws



Power Cable



Power Adapter



Mini Pendant

## System Requirements

- CPU: Pentium 4 1.4GHz or above
- Hard Disk: 40GB or above
- Memory: 256MB or above
- Browser: Internet Explorer 7.0 or above
- Video Resolution: SVGA or XGA (1024x768 or above)

# Hardware Overview

**Mounting Point:** This part of the cap is used to mount the dome camera enclosure.

**Cap:** This cap covers the Connection Panel.

**Optical Cover:** This clear dome protects the camera apparatus from.



**Dome Camera**

**Reset Button:** The button can be used to reset the system or restore the factory default settings. To reset, simply press and hold the button for 10 seconds.

**Power Socket:** This is 3 pin socket accepts the power cable.



Pin	Definition
1	AC 24-
2	FG
3	AC 24+


**RJ45 connector:** Connect you category 5 ethernet cable to this port.



Green Link Light indicates good network connection.  
Orange Activity Light flashes for network activity indication.

# Hardware Overview


**Alarm I/O:**Support two digital alarm outputs and four digital alarm inputs.



Pin	Definition
1	ALARM_OUT_NO_1
2	ALARM_OUT_NC_1
3	ALARM_OUT_COM_1
4	GND
5	ALARM_OUT_NO_2
6	ALARM_OUT_NC_2


Pin	Definition
7	ALARM_OUT_COM_2
8	GND
9	ALARM_IN_4
10	ALARM_IN_3
11	ALARM_IN_2
12	ALARM_IN_1

**Audio I/O:**Support one audio input and one audio output.



Pin	Definition
1	LINE_OUT
2	GND
3	LINE_IN

**Micro SD card slot:**Support micro sd card storage.



**Connections Panel**

# Hardware Installation

## STEP 1

Unpack the DCS-6915 and remove the dome camera unit.



## STEP 2

Remove the protective cover and PE sheet.



## STEP 3

Apply some lubricant on the cover's waterproof seal to make the installation process smoother. Attach the optical cover to the camera body.

The small protrusions on the cover must align with the four holes on the camera body.



## STEP 4

Gently press down the dome cover with two hands on the side of it.

**Warning:** DO NOT press down on the optical cover. This might cause damage to the camera.



## STEP 5

Screw the dome cover and body together.



# Hardware Installation

## STEP 6

Insert the Power connector into the opening on the cap.



## STEP 7

Connect the 3-pin connector to the slot on the camera enclosure. The connector will lock into place.



## STEP 8

Connect the power cable to the power adapter.




## STEP 9

Connect one end of the CAT 5 Ethernet cable to the RJ-45 connector of the camera enclosure, and the other end of the cable to your network.

## STEP 10

Insert the MicroSD card into the slot.



## STEP 11

Plug the power cable into a wall outlet.



# Software Installation


Insert the DCS-6915 CD into the CD-ROM drive. If the CD Autorun function does not automatically start on your computer, click Windows® Start > Run. In the Run command box type "**D:\autorun.exe**", where D: represents the drive letter of your CDROM. If it does start, proceed to the next screen.

Click **Setup Wizard**




Click **Next** to continue.

Click **Next**



Click **Yes** to accept the License Agreement.



Click **Yes**



To start the installation click **Next**.


**Note:** The installation may take several minutes to complete.

Click **Next**



Click **Finish** to complete the installation.

Click **Finish**



# Configuring Your Camera with the Installation Wizard

Click on the **D-Link Setup Wizard SE** icon that was created in your Windows Start menu.

The Setup Wizard will appear and show the MAC address of the DCS-6915 and an IP Address (which may or may not be correct depending on what you have your DCS-6915 connected to). If you have a DHCP server on your network, there will be a valid IP Address displayed here.

**Note: A DHCP server is a device that supplies IP addresses to your network devices automatically.**

Your camera's IP Address will be displayed here along with its corresponding MAC Address.

Click the **Wizard** button

MAC Address	Current IP Address	Device Name
00:6 11 11 00 88	192.168.0.20	DCS-6915

Enter the admin ID and password.

**Note: The default Admin ID is admin with the password left blank.**


Click **Next**

Select DHCP if you want to obtain a new IP address every time the camera boots up, or select static IP to use the same IP address at each boot up.


Click **Next**

# Viewing Your Internet Camera

Click the button labeled **Link** to access the web configuration. The Setup Wizard will automatically open your web browser to the IP address of the DCS-6915, in this example it is: <http://192.198.0.20>. Your camera may have a different IP Address.




Enter **admin** as the default username and leave the password blank. Click **OK** to continue.



This section shows your camera's live video. You can control your settings using the buttons below. For more information on using the web configuration, please refer to the user manual.

Install the **ActiveX** control to view live video.



# Standard or Mini Pendant Mount


Follow the steps below to mount the camera enclosure with the pendant mount.

## STEP 1

Make a cable entry hole on the wall to recess the cables. Alternatively, cables can be threaded through the cable entry hole on the mounting plate.

## STEP 2

To prevent insects from entering the pendant mount, you may block the cable entry hole with the supplied sponge in two different ways.



## STEP 3

Thread the cables through the pendant mount and affix the pendant mount on the wall with screws and screw anchors (not supplied).



## STEP 4


Attach the waterproof collar to the pendant mount.

## STEP 5

Thread the cables through the cap and affix it to the pendant mount with the supplied screws and washers.

## STEP 6

Connect the cables to the camera enclosure. Attach the camera enclosure to the mount and affix it with the supplied bolt.



**Note:** After threading the cables, please block the cable entry hole with the supplied sponges to prevent insects from entering the tube.

## TECHNICAL SUPPORT

**United Kingdom (Mon-Fri)** , Website: <http://www.dlink.com>

Home Wireless/Broadband 0871 873 3000 (9.00am–06.00pm, Sat 10.00am-02.00pm)

Managed, Smart, & Wireless Switches, or Firewalls 0871 873 0909 (09.00am- 05.30pm)

(BT 10ppm, other carriers may vary.)

**Ireland (Mon-Fri)**, Website: <http://www.dlink.com>

All Products 1890 886 899 (09.00am-06.00pm, Sat 10.00am-02.00pm)

Phone rates: €0.05ppm peak, €0.045ppm off peak times